

Provided hardware

One Polished 3 3/8" Adapter Ring

Two 3 1/8" Gauge Mounting Brackets

One 3 3/8" Mounting Ring

Six 8-32 Nuts

Two 1/8" Z-shaped brackets

- 1) Install your 3 3/8" quad gauge into the polished ring. We have provided a 3 3/8" mounting ring to guide the mounting brackets provided by Auto Meter. This ring goes behind the polished panel. The Auto Meter mounting should be placed into the two grooves, preventing them from sliding outward.
- 2) Install the polished ring into your vehicle using two 8-32 nuts & two 1/4" Z-shaped brackets.
- 3) Intstall the two 3 1/8" gauges into your vehicle using two 8-32 nuts per side.

