

Included mounting hardware:

Five # 10 x 1/2" sheet metal screws

Four # 10 x 3/4" sheet metal screws

Two #10 speed nuts

- 1) Cut your original gauge bezel to allow clearance for the gauges.
- 2) Secure the original gauge bezel to your vehicle using three #10 x 1/2" sheet metal screws, using the three location on top only. Attempting to screw these in after installing the gauge panel usually results in scratching the finish.
- 3) Install your gauges using the hardware provided by the gauge manufacture.
- 4) Install the LED lights.
- 5) Secure the gauge panel to the original bezel using four #10 x 3/4" sheet metal screws (on bottom) and two 1/2" #10 x 1/2" sheet metal screws & two #10 speednuts on top.
- 6) Wire your gauges per gauge manufacturers instructions.

